

# SUNROOF INFORMATION & FIT GUIDE

## 1989 -1995

### Proper Location of Sunroof

Determine the front to back position of the sunroof by placing the template inside the vehicle and determining the best possible position on the headliner. Transfer this position to the outside roof skin by dimpling the roof with an awl poked through the template at least 4 inches within the cut out area. Establish the vehicle centerline by measuring side to side on the vehicle and dividing by two. Center the template on this line using the dimple to establish the front to back position. These specifications are intended to be guidelines only. Car manufacturers may change specifications without notice.

**SFC Sunroofs (Stretch Forming Corp.) and CRL do not accept responsibility for any sunroof location. It is the installer s responsibility to check and verify each application before beginning the installation.**

### Interior Trim Ring Selection

The selection of the proper trim ring reflects an installer s choice, technique and ability. The T5 & T6 trim rings are universal and can be adapted to a variety of headliner thicknesses. Adapting the ring to the desired configuration is shown on the installation instructions provided with the sunroof. The objective is to create a stack dimension that will firmly squeeze the sealant, steel rooftop, shim and headliner together. (Approx. 7/8 Inch) If a trim ring other than the one pre-assembled to your sunroof is used, be sure to pre-assemble this new ring to the frame for easier installation.

#### THE CRL/SFC SUNROOF FIT GUIDE

This application/fit guide offers suggested sunroof applications for vehicles from 1989 to 1995. Preferred applications are marked with **XX**. Additional sunroofs will fit these vehicles and are marked with a single X. Setback measurements are not listed in this guide but can be determined as indicated in The Proper Location of Sunroof section of this page.

Setback measurements as well as other information are published and available in specific yearly application guides for 1996 — 2001 vehicles.

<b>CRL/SFC</b>	<b>SUNROOF FIT GUIDE 1989 - 1995</b>												
<b>Make/Model</b>	<b>Year</b>	<b>AP 1530</b>	<b>AP 1735</b>	<b>NP 1432</b>	<b>NP 1636</b>	<b>NP 1828</b>	<b>NP 1828D</b>	<b>NP 2238</b>	<b>NP/GS 1732</b>	<b>NP/GS 2032</b>	<b>GS 1528</b>	<b>ES 100</b>	<b>ES 300/500</b>
<b>Acura</b>													
Integra	89 - 95	x		x		x	xx		x	x	x	x	x
Vigor	93 - 95			x		x	x		x	xx	x	x	x
<b>Buick</b>													
Century	89 - 95	x	x	x	x	x	x		x	xx	x	x	x
Estate Wagon	90 - 95			xx									
Le Sabre	89 - 95	x	x	x	x	x	x		x	xx	x	x	x
Park Avenue	89 - 95	x	x	x		x	x		x	xx	x	x	x
Reatta	89 - 90	x		xx							x		
Regal	89 - 95	x	x	x	x	x	x		x	xx	x	x	x
Riviera	89 - 95					x	x			xx		x	x
Road Master	95			x	xx	x	x		x	x	x	x	x
	92 - 94		x	xx	x	x	x	x	x	x	x	x	x
Skyhawk	89	x		x		x	x		xx	x	x	x	x
Skylark	92 - 95					xx	x						
	89 - 91	x		x		x	x		x	xx	x	x	x
<b>Cadillac</b>													
Brougham	90 - 94	x	x	x	x	x	x		x	xx	x	x	x
Concours	94		x						x	xx		x	x
De Ville	94 - 95					x	x		x	xx		x	x
	90 - 93	x	x	x	x	x	x		x	xx	x	x	x
El Dorado	94 - 95					x	x		x	xx		x	x
	90 - 93	x	x	x	x	x	x		x	xx	x	x	x
Fleetwood	94		x						x	xx		x	x
	90 - 93	x	x	x	x	x	x		x	xx	x	x	x
Seville	94 - 95					x	x		x	xx		x	x
	90 - 93	x	x	x	x	x	x		x	xx	x	x	x
<b>Chevrolet</b>													
Beretta	89 - 95	x		x			x		x	xx	x	x	x
Camaro	89 - 92	x		x		x	x		x	xx	x	x	x
Caprice	90 - 95	x	xx	x	x	x	x		x	x	x	x	x
Caprice Wagon	92 - 95	x	xx	x	x	x	x		x	x	x	x	x
Cavalier 2 Dr	95	x		x		x	xx		x	x	x	x	x
Cavalier 4 Dr	95					x	xx				x		
Cavalier	89 - 94	x		x		x	x		x	xx	x	x	x
CK Pickup	89 - 95	x	x	x	xx	x	x	x	x	x	x	x	x
Corsica	89 - 95	x		x		x	x		x	xx	x	x	x
Impala SS	95	x	x	x	x	x	x		x	xx	x	x	x
Lumina Coupe	91		x	x					x	xx			
	90		xx	x									
Lumina Sedan	95	x	x	x	x	x	x		x	xx	x	x	x
	90 - 94		x	x		x	x		x	xx		x	x
Lumina Van	95	x		x	xx				x		x	x	
	91 - 94	x	xx	x	x				x		x	x	
Suburban	89 - 95	x	x	x	xx	x	x		x	x	x	x	x
S-10	94 - 95	x	x	x	xx	x	x		x	x	x	x	x
	89 - 93	x	x	x	xx	x	x		x		x	x	
S-10 Ext Cab	94 - 95	x	x	x	xx	x	x	x	x	x	x	x	x
	89 - 93	x		x		x	x		x	xx	x	x	x
Tahoe	95	x	x	x	xx	x	x		x	x	x	x	x
<b>Chrysler</b>													
Cirrus	95			x		x	xx		x	x	x	x	x
Concorde	93 - 95	x		x		x	xx		x	x		x	x

<b>CRL/SFC</b>	<b>SUNROOF FIT GUIDE 1989 - 1995</b>												
<b>Make/Model</b>	<b>Year</b>	<b>AP 1530</b>	<b>AP 1735</b>	<b>NP 1432</b>	<b>NP 1636</b>	<b>NP 1828</b>	<b>NP 1828D</b>	<b>NP 2238</b>	<b>NP/GS 1732</b>	<b>NP/GS 2032</b>	<b>GS 1528</b>	<b>ES 100</b>	<b>ES 300/500</b>
<b>Chrysler (Continued)</b>													
Imperial	90 - 93	x	x	x	x	x	x		x	XX	x	x	x
Le Baron	90 - 94	x		x		x	x		x	XX	x	x	x
LHS	94 - 95	x	x	x	x	x	x		x	XX	x	x	x
New Yorker	90 - 95	x	x	x	x	x	x		x	XX	x	x	x
Salon	91	x	x	x	x	x	x		x	XX	x	x	x
Sebring	95					x	XX		x	x		x	x
Town and Country	91 - 95			XX									
<b>Daihatsu</b>													
Charade	89 - 92	x		x		x	x		XX	x	x	x	x
<b>Dodge</b>													
Avenger	95			x		x	x		XX	x			
Caravan	92 - 95			x	x				XX				
Charger	91 - 93	x	x	x	x	x	x	x	x	XX	x	x	x
Colt	89 - 94	x		x		x	x		XX	x	x	x	x
Colt Vista Wagon	89 - 90	x		x		x	x		XX	x	x	x	x
Dakota	89 - 95	x	x	x	XX	x	x		x	x	x	x	x
Daytona	89 - 93	x		XX		x	x		x	x	x	x	x
Dynasty	89 - 93	x	x	x	x	x	x		x	XX	x	x	x
Intrepid	93 - 95	x		x		x	x		x	XX	x	x	x
Monaco	90 - 92	x	x	x	x	x	x		x	XX	x	x	x
Neon	93 - 95	x		x		x	XX		x	x	x	x	x
Omni	89 - 90	x		x		x	x		XX	x	x	x	x
Ram Std Cab	89 - 95	x	x	x	x	x	x		x	XX	x	x	x
Ram Ext Cab	89 - 95	x	x	x	x	x	x		x	XX	x	x	x
Ram Van	89 - 95	x						XX		x	x		x
Shadow	89 - 94	x		XX		x	x		x	x	x	x	x
Spirit	89 - 95	x		XX		x	x		x	x	x	x	x
Stealth	91 - 95			x		XX	x		x	x	x	x	x
Stratus	95	x		x		XX	x		x	x	x	x	x
<b>Eagle</b>													
Premier	89 - 92	x		x		x	x		XX	x	x	x	x
Summit	89 - 95	x		x		x	x		XX	x	x	x	x
Summit Wagon	92 - 95	x		x		x	x		XX	x	x	x	x
Talon	89 - 95	x		x		XX	x		x	x	x	x	x
Vision	93 - 95	x		x		x	x		XX	x	x	x	x
<b>Ford</b>													
Aerostar	90 - 95			XX									
Aspire	94 - 95	x		x		XX	x		x	x	x	x	x
Bronco	92 - 95	x	XX	x	x	x	x	x	x	x	x	x	x
	90 - 91	x	XX	x	x				x		x		
Bronco II	89 - 90	XX	x	x	x				x		x		
Contour	95	x		x		x	XX		x	x	x	x	x
Crown Victoria	93 - 95					x	x		x	XX		x	x
	89 - 92	x	x	x	x	x	x		x	XX	x	x	x
Econoline Van	89 - 95			x	XX						x		
Escort	89 - 95	x		x		x	x		XX	x	x	x	x
Escort Wagon	93 - 95			XX							x		
	89 - 92	x		XX					x		x		
Explorer	91 - 95	x	x	x		x	x		x	XX	x	x	x
Festiva	91 - 94	x		x		x	x		x	XX	x	x	x
	89 - 90	XX											
F-Series	92 - 95	x	x	x	XX	x	x	x	x	x	x	x	x
	89 - 91	x	XX	x	x	x	x		x		x	x	

<b>CRL/SFC</b>	<b>SUNROOF FIT GUIDE 1989 - 1995</b>													
<b>Make/Model</b>	<b>Year</b>	<b>AP 1530</b>	<b>AP 1735</b>	<b>NP 1432</b>	<b>NP 1636</b>	<b>NP 1828</b>	<b>NP 1828D</b>	<b>NP 2238</b>	<b>NP/GS 1732</b>	<b>NP/GS 2032</b>	<b>GS 1528</b>	<b>ES 100</b>	<b>ES 300/500</b>	
<b>Ford (Continued)</b>														
Crew Cab	89 - 95	X	X	X	XX	X	X	X	X	X	X	X	X	
Mustang	95					X	XX			X		X	X	
	93 - 94	X		X		X	X		X	XX	X	X	X	
	91 - 92	X	X	X	X	X	X		X	XX	X	X	X	
	89 - 90	X		X		X	X		X	XX	X	X	X	
Probe	89 - 95	X		XX		X	X		X	X	X	X	X	
Ranger Std Cab	89 - 95	X		X	XX				X		X			
Ranger Ext Cab	89 - 95	X		X	XX				X		X			
Taurus	89 - 95	X		X		X	XX		X	X	X	X	X	
Taurus Wagon	89 - 95	X		XX					X		X	X		
Tempo	89 - 94	X		X		X	X		XX	X	X	X	X	
Thunderbird	89 - 95	X		X		X	X		X	XX	X	X	X	
Windstar	94 - 95	X		X		X	X		XX	X	X	X	X	
<b>GMC</b>														
Jimmy	95	X	X	X	XX	X	X		X	X	X	X	X	
	94	X	X	X	XX				X		X			
	89 - 93	X	X	X	X	X	X	XX	X	X	X	X	X	
S-15 Jimmy	89 - 93	X	X	X	XX	X	X		X	X	X	X	X	
Sierra	94 - 95	X	X	X	XX	X	X	X	X	X	X	X	X	
Sonoma	92 - 95	X	X	X	XX	X	X		X	X	X	X	X	
Suburban	94 - 95	X	X	X	XX	X	X	X	X	X	X	X	X	
Cyclone/Typhoon	92 - 93	X	X	X	XX	X	X		X	X	X	X	X	
Yukon	94 - 95	X	X	X	XX	X	X	X	X	X	X	X	X	
<b>Honda</b>														
Accord	89 - 95	X		X		XX	X		X	X	X	X	X	
Civic	89 - 95	X		X		XX	X		X	X	X	X	X	
CRX	89 - 92	X		X		XX	X		X		X	X		
Passport	94 - 95	X	X	X	XX	X	X		X	X	X	X	X	
Odyssey	95			X	XX				X		X			
<b>Hyundai</b>														
Accent	95	XX		X		X	X		X	X	X	X	X	
Elantra	92 - 95	X		X		X	X		XX	X	X	X	X	
Excel	89 - 94	XX		X		X	X		X	X	X	X	X	
Scoupe	91 - 95	X		X		XX	X		X	X	X	X	X	
Sonata	89 - 95	X		XX		X	X		X	X	X	X	X	
Tiburon	95	X		X		XX	X		X	X	X	X	X	
<b>Infiniti</b>														
G20	91 - 95	X		X		X	X		X	XX	X	X	X	
<b>Isuzu</b>														
Amigo	91 - 95	X	XX	X	X	X	X		X	X	X	X	X	
Rodeo	91 - 95	X	X	X	X	X	X		X	XX	X	X	X	
Trooper	92 - 95	X	XX	X	X	X	X	X	X	X	X	X	X	
	89 - 91			XX							X			
Impulse	91 - 92	XX		X		X	X		X	X	X	X	X	
<b>Jeep</b>														
Cherokee	91 - 95		XX	Specialty 1735 (joggled roof) AP1735B5H1										
Comanche	92 - 93	X	XX	X		X	X		X	X	X	X	X	
	89 - 91	X	XX	X					X		X			
Grand Cherokee	93 - 95			Specialty 2032 (joggled roof) NP2032B5H7						XX				
Wrangler	89 - 95	X	XX	X	X	X	X	X	X	X	X	X	X	
<b>Kia</b>														
Sephia	94 - 95			XX		X	X		X	X	X	X	X	
Sportage	95	X		X		X	X		X	XX	X	X	X	

<b>CRL/SFC</b>	<b>SUNROOF FIT GUIDE 1989 - 1995</b>												
<b>Make/Model</b>	<b>Year</b>	<b>AP 1530</b>	<b>AP 1735</b>	<b>NP 1432</b>	<b>NP 1636</b>	<b>NP 1828</b>	<b>NP 1828D</b>	<b>NP 2238</b>	<b>NP/GS 1732</b>	<b>NP/GS 2032</b>	<b>GS 1528</b>	<b>ES 100</b>	<b>ES 300/500</b>
<b>Land Rover</b>													
	95	x		x					xx				
<b>Lincoln</b>													
Continental	94 - 95	x	x	x		x	x		x	xx	x	x	x
	89 - 93			x		x	x		x	xx	x	x	x
Mark VIII	94 - 95	x		x		x	x		x	xx	x	x	x
Mark VII	89 - 92			x		x	x		x	xx	x	x	x
Town Car	94 - 95	x	x	x	x	x	x	x	x	xx	x	x	x
	89 - 93			x					x	xx	x	x	x
<b>Mazda</b>													
323	89 - 94	x		x		x	x		xx	x	x	x	x
626	91 - 95	x		x		x	x		xx	x	x	x	x
929	89 - 94	x		x		x	x		xx	x	x	x	x
B Series Trucks	89 - 93	x	xx	x	x	x	x		x		x	x	
B Series Ext Cab	92 - 93	x	xx	x	x	x	x	x	x	x	x	x	x
MPV Van	94 - 95	x	x	x	xx	x	x		x	x	x	x	x
MX-3	92 - 95	x		xx		x	x		x	x	x	x	x
MX-5 Miata	92 - 95	x		xx							x		
MX-6	89 - 95	x		x		x	x		xx	x	x	x	x
Navajo	92 - 94	x	xx	x	x	x	x	x	x	x	x	x	x
Pickup Std Cab	94 - 95	x		x	x				xx		x		
Pickup Ext Cab	94 - 95	x		x	x				xx		x		
Prot g	91 - 95	xx		x		x	x		x	x	x	x	x
<b>Mercury</b>													
Cougar	89 - 95	x		x		x	x		x	xx	x	x	x
Grand Marquis	93 - 95					x	x		x	xx		x	x
	89 - 92	x		x		x	x		x	xx	x	x	x
Mystique	95	x		x		x	xx		x	x	x	x	x
Sable	89 - 95	x		x		x	xx		x	x	x	x	x
Sable Wagon	89 - 95	x		xx					x		x		
Topaz	89 - 94	x		x		x	x		xx	x	x	x	x
Tracer	95	x		x		x	x		xx	x	x	x	x
Tracer Wagon	95			xx							x		
Villager	93 - 95	x		x		x	x		x	xx	x	x	x
<b>Mitsubishi</b>													
3000 GT	93 - 95	x		x		xx	x		x	x	x	x	x
	91 - 92	x		x		xx			x		x	x	
Diamonte	92 - 95			x		x	x		x	xx	x	x	x
Eclipse	89 - 95	x		x		xx			x		x	x	
Expo LRV	92 - 94	x		x		x	x		xx	x	x	x	x
Galant	95	x		xx					x	x	x		x
	89 - 94	x		xx		x	x		x	x	x	x	x
Mirage	89 - 95	x		x		x	x		xx	x	x	x	x
Montero	89 - 95	x	xx	x	x	x	x	x	x	x	x	x	x
Mighty Max	92 - 95	x	xx	x	x	x	x		x	x	x	x	x
	91	x	xx	x	x	x	x		x		x	x	
Precis	89 - 93	x		x		x	x		xx	x	x	x	x
200 SX	95	x		x		x	x		x	xx	x	x	x
240 SX	89 - 95	x		x		xx	x		x	x	x	x	x
Altima	93 - 95	x		x		x	x		xx	x	x	x	x
Axxess	90	x		x		x	x		xx	x	x	x	x
Pickup	92 - 95	x	xx	x	x	x	x		x	x	x	x	x
	89 - 91	x	xx	x	x	x	x		x		x	x	
<b>CRL/SFC</b>	<b>SUNROOF FIT GUIDE 1989 - 1995</b>												

Make/Model	Year	AP 1530	AP 1735	NP 1432	NP 1636	NP 1828	NP 1828D	NP 2238	NP/GS 1732	NP/GS 2032	GS 1528	ES 100	ES 300/500
<b>Nissan (Continued)</b>													
Maxima	89 - 95	X		X		X	X		X	XX	X	X	X
NX	91 - 93	X		X		X	X		X	XX	X	X	X
Pathfinder	89 - 95	X	X	XX					X		X		
Sentra	89 - 95	X		XX		X	X		X	X	X	X	X
Quest	92 - 95	X		X		X	X		XX	X	X	X	X
<b>Oldsmobile</b>													
88	90 - 95	X	X	X	X	X	X		X	XX	X	X	X
98 Regency	89 - 95	X	X	X	X	X	X		X	XX	X	X	X
Achieva	92 - 95					XX	X					X	
Aurora	94 - 95					XX	X		X	X		X	X
Bravada	90 - 95	X	XX	X	X	X	X		X		X	X	
Custom Cruiser	91 - 93			XX									
	89	X		XX		X	X		X	X	X	X	X
Cutlass	89 - 95	X		X		X	X		X	XX	X	X	X
Elite	91	X	X	X	X	X	X		X	XX	X	X	X
Silhouette	90 - 95	X	X	X	XX				X		X		
Toronado	90 - 92	X	X	X	X	X	X	X	X	XX	X	X	X
Trofeo	89 - 91	X		X		X	X		X	XX	X	X	X
<b>Peugeot</b>													
405	90 - 91	X		X		X	X		XX	X	X	X	X
405 Wagon	90 - 91	X		X		X			XX		X	X	
505	90 - 91	X		X		X	X		XX	X	X	X	X
505 Wagon	90 - 91	X		X		X			XX		X	X	
<b>Plymouth</b>													
Acclaim	89 - 95	X		X		X	X		XX	X	X	X	X
Duster	93	XX		X		X			X		X	X	
Horizon	89	XX		X		X	X		X	X	X	X	X
Laser	89 - 94	X		XX		X	X		X		X	X	
Neon	95	X		X		X	XX		X	X	X	X	X
Sundance	89 - 94	X		XX		X	X		X	X	X	X	X
Voyager	95			X	XX								
	89 - 94			X					XX				
<b>Pontiac</b>													
6000 Wagon	89 - 91		X	X	XX	X	X		X		X	X	
Bonneville	89 - 95	X	X	X	X	X	X		X	XX	X	X	X
Firebird	91 - 92	X	X	XX	X	X	X		X	X	X	X	X
	89 - 90	X		X		X	X		X	XX	X	X	
Grand Am	92 - 95					XX					X		
	89 - 91	X		X		X	X		X	XX	X	X	X
Grand Prix	89 - 95	X	X	X	X	X	X		X	XX	X	X	X
Grand Prix Sedan	89 - 91		X	X	X	X	X		X	XX	X	X	X
LeMans	90 - 93	X		X		X	X		X	XX	X	X	X
Sunbird	93 - 94	X		X		X	X		XX	X	X	X	X
	89 - 92	X	X	X	X	X	X		XX	X	X	X	X
Sunfire 2 Dr	95					X	XX						
Trans Sport	91 - 95	X	X	X	XX				X		X		
<b>Saab</b>													
900	89 - 95	X		X		X	X		X	XX	X	X	X
9000	94 - 95					X	X			XX		X	X
<b>Saturn</b>													
SC	91 - 95	X		X		X	X		XX	X	X	X	X
SL	91 - 95	X		X		X	X		X	XX	X	X	X
SW	93 - 95	X		X		X	X		XX		X	X	

CRL/SFC		SUNROOF FIT GUIDE 1989 - 1995											
Make/Model	Year	AP 1530	AP 1735	NP 1432	NP 1636	NP 1828	NP 1828D	NP 2238	NP/GS 1732	NP/GS 2032	GS 1528	ES 100	ES 300/500
<b>Subaru</b>													
Impreza	93 - 95	x		x		x	x		x	XX	x	x	x
Impreza Wagon	94 - 95	x		XX		x	x		x	x	x	x	x
Justy	89 - 94	x		x		XX	x		x	x	x	x	x
Legacy	91 - 95	x		x		x	x		x	XX	x	x	x
Legacy Wagon	95	x		XX					x		x		
	91 - 94	x		XX		x	x		x		x	x	
Loyale	92 - 94	x		x		x	x		XX		x	x	
Loyale Wagon	90 - 91	x		XX		x	x		x	x	x	x	x
<b>Suzuki</b>													
Sidekick	89 - 95	XX	x	x		x	x		x	x	x	x	x
Swift	89 - 95					x	XX					x	
<b>Toyota</b>													
4-Runner	95	x		x	x	x	x		XX	x	x	x	x
	94	x	x	x	x	x	x		XX	x	x	x	x
	89 - 93	x	x	x	x	x	x		XX		x	x	
Avalon	95			x		x	x		x	XX		x	x
Camry	89 - 95	x		x		x	x		x	XX	x	x	x
Camry Wagon	94 - 95	x		XX		x	x		x		x	x	
	89 - 93	x		XX		x	x		x	x	x	x	x
Celica	94 - 95	x		x		x	XX		x	x	x	x	x
	91 - 93	x		x		x	x		XX		x	x	
	89	x		x		x	x		XX	x	x	x	x
Corolla	89 - 95	x		x		x	x		XX	x	x	x	x
Corolla Wagon	89 - 94	x		XX		x	x		x		x	x	
Land Cruiser	89 - 95	x	XX	x	x	x	x		x	x	x	x	x
Paseo	92 - 95	x		x		XX	x		x	x	x	x	x
Pickup	89 - 94	x	x	x	XX	x	x		x	x	x	x	x
Previa	91 - 95	x		x	XX				x		x		
T-100	93 - 95	x	x	x	XX	x		x	x	x	x	x	x
Tacoma	95	x		x	XX	x	x		x	x	x	x	
Tercel	89 - 95	x		x		x	XX		x	x	x	x	x
<b>Volkswagen</b>													
Corrado	91 - 94	x		x		x			XX		x	x	
Fox	89 - 93	x		XX		x	x		x	x	x	x	x
Golf & GTI	89 - 95	x		x		x	x		x	XX	x	x	x
Jetta	89 - 95	x		x		x	x		x	XX	x	x	x
Passat	90 - 95	x		x		XX	x		x	x	x	x	x
Passat Wagon	90 - 95	x		x		XX			x		x		
<b>Volvo</b>													
240	91 - 93	x		x		x	x		x	XX	x	x	x
	89 - 90	x		x		x			XX		x	x	
740	90 - 93	x		x		x	x		x	XX	x	x	x
740 Wagon	90 - 93	x		x		x	x		x	XX	x	x	x
760	90 - 93	x		x		x	x		x	XX	x	x	x
780	90	x		x		x	x		x	XX	x	x	x
940	94 - 95	x		x					XX		x		
960	94 - 95	x		x					XX		x		
<b>Yugo</b>													
GV	89 - 92	XX		x		x	x		x	x	x	x	x